

ATOM Wall Switch Manual

Battery Operated

P/N: 77-0150 REV: A 02/05/2025

The ATOM Wireless Wall-mount Switch is designed to replace traditional in-wall switch with modern wireless technologies. It is capable of providing multi-functions and allow wirelessly control lighting devices in various platforms. This is a must have components to excel user experiences in the wireless environment.

KEY FEATURES:

- Easy Installation, allows you to add a wall switch anywhere you want without running wires & paying for an electrician.
- Best low power load support, no bypass part or low power light adapter required
- Default local circuit operate and do not require system control
- BT 5.0 compatible Casambi BT 5.0 Mesh
- Power failure memory to return to its previous set level prior to the interruption of power
- Compatible to designer style wall-plates or standard off-the-shelve wall plates
- Fit in 1-gang U.S. wall-box; 2 1/2" minimum depth recommended
- Neutral with required design make installation easier.

SPECIFICATION:

Compatibility Voltage

Operating Environment Radio Properties Internal Antenna

Controls Battery type

Dimensions Warranty ZigBee Pro; BT 5.0

3VDC

0 - 50 Deg. C 2.4GHz Built-in

: 2 to 8 buttons for on/off; dim; scene selection

: Four AAA Batteries (Not Included) : 15.8 x 70 x 112.9mm (L x W x H)

: 5 Year

BUTTON PRESSING INSTRUCTIONS



Short press: Sends "ON" instruction to lights that are bound to this switch and also controls its local Relay to ON position.

Press: Send "Step Up" (with On/Off), and then send "Stop" as soon as released.

1

Short press: Send "Recall scene (scene ID=1)"

3

Short press: Send "Recall scene (scene ID=3)"



Short press: Sends "OFF" instruction to lights that are bound to this switch and also controls its local Relay to OFF position.



Press: Send "Step Down" (with On/Off), and then send "Stop" as soon as released.



Short press: Send "Recall scene (scene ID=2)"



Short press: Send "Recall scene (scene ID=4)"

FACTORY RESET (ZIGBEE ONLY)







Long press (6 seconds or longer) simultaneously until all button indicators are lit, then release the buttons. All button indicators will blink in 1 second interval if factory reset successfully. (Zigbee only)

WAKE UP (CASAMBI ONLY)



Press and release 1 and 2 at the same time.

LED INDICATORS STATUS AND SLEEP/ WAKEUP INTERVALS

	ZIGBEE	CASAMBI
SWITCH NOT COMMISSIONED	All 8 buttons will blink in 1 second interval when in non-commissioned state. It stays awake and searches for network for 16 seconds, and then goes to sleep for 20 seconds. Repeats this iteration for only 15 minutes and then goes to deep sleep, waiting for a manual press to be woken up.	Preset buttons will blink in 1 second interval when it doesn't join to any network
SWITCH COMMISSIONED	After it joins a network, only the pressed button will be lit. Upon powered on, all 8 buttons blinks for 3 seconds and then off.	1. After it joins a network, only select the preset button will be lit; 2. it will enter sleep mode after 20 second; 3. Press and release preset button 1 and 2 to wake up the switch;
POWER SAVE MODE	It will not show in the nearby devices any more but all buttons are still functional. To bring it back online for configuration, just press and release button 1 and 2 at the same time.	Wake up mode.





